



The Australian Wine
Research Institute

Using sensors to monitor sugar levels during fermentation


Tadro Abbott

Project Engineer, AWRI Commercial Services

The Fermentation Process



The Australian Wine
Research Institute



Fermentation process monitoring



The Australian Wine
Research Institute



Objectives



The Australian Wine
Research Institute



ESTD 1928
De BORTOLI
FAMILY WINEMAKERS

Evaluation criteria



The Australian Wine
Research Institute

- Cost
- Ease of installation
- Connectivity
- Setup/calibration
- Sensitivity to process environment
- Accuracy and repeatability



Screening technology options



The Australian Wine
Research Institute

Sensor	Supplier	Measurement principle	Indicative cost (per unit)	Difficulty
Liquiphant Vibrating Fork	Endress & Hauser	Density	\$2-3K	Moderate
Deltapoint S	Endress & Hauser	Hydrostatic pressure	\$3K combined	High
Micropilot	Endress & Hauser	Volume (level)		High
Fermetrol	Psitec	Osmotic potential	\$2K	Moderate
MicroLDS	ISSYS	Mass flow (liquid)	\$1K	Low
VS-3000	Vital Sensors	Mid-IR absorbance	\$3K	Moderate
Proline t-mass	Endress & Hauser	Mass flow (gas)	\$3K	Moderate
Biosensor	OptiEnz	Enzyme response	\$1-2K	Low



Process sensor 1




Liquiphant vibrating fork


Measures density via changes in
oscillation frequency

Density converted into Baume
reading

Density Computer accommodates up
to 4 sensor inputs



Process sensor 2





Fermetrol probe

Measures osmotic potential in grape juice

Expansive pressure in semi-permeable polymer converted into electrical signal

Initial Baume required to convert signal into 'inferred' Baume reading



Process sensor 3



The Australian Wine
Research Institute



Micro-LDS sensor

Micro-coriolis flowmeter

Measures flowrate, temperature,
density and viscosity

Density readings converted into Baume


Flow through sensor – connected to
sample tap

Petaluma Trial 2015



The Australian Wine
Research Institute

- 6.5 kL white fermenter
- Vibrating fork & Fermetrol probe mounted through modified door panel
- Micro-LDS fed from sample tap
- Fork data converted in Density Computer & locally logged
- Fermetrol data stored locally
- Micro-LDS measurements taken every 2hrs via solenoid valve & filter
- Samples taken daily by lab for reference analysis




De Bortoli Trial 2015



The Australian Wine
Research Institute


- 200 kL red fermenter
- Sensors mounted in by-pass loop
- 400 μm filter to reduce solids in flow stream
- Restrictor to reduce turbulent flow and bubbles
- Local data management station to process sensor outputs
- Samples taken daily by lab for reference analysis



Vibrating fork data – white ferments




The Australian Wine Research Institute



Vibrating fork data – white ferments



The Australian Wine Research Institute



Vibrating fork data – white ferments




The Australian Wine
Research Institute



Vibrating fork – red ferments YALUMBA



The Australian Wine Research Institute



Data supplied by Yalumba Wines



Vibrating fork data – red ferments



The Australian Wine
Research Institute




Image courtesy of Endress/Hauser & Yalumba Wines

Fermetrol data – white ferments




The Australian Wine Research Institute



Fermetrol– red ferments ST HALLETT



The Australian Wine
Research Institute




Data supplied by St. Hallett Wines/Psitec



Micro-LDS data – white ferments




The Australian Wine Research Institute



Micro-LDS data – white ferments



The Australian Wine Research Institute



- Commercial sensors do provide a viable option

BUT

- Implementation is not simple
- Fermentation is a harsh environment
- Solids pose various problems



Need to be willing to spend the time to get it right



Cost benefit analysis



Winery size	Crush (t)	Approx. no. tanks	Total no. ferments/vintage	Tank size (average kL)	Av. kL processed
Small	<500	10	30	7.5	225
Medium	500-2,500	25	75	15	1,125
Large	2,500-50,000	50	150	50	7,500
Huge	>50,000	100	300	250	75,000

Winery size	Crush (t)	Total initial investment (\$)	Operating expenses (\$ p.a.) initial year	Operational savings (\$ p.a.) initial year	Payback period (years)
Small	<500	22,500	272	15,367	2.79
Medium	500-2,500	56,250	672	36,542	2.36
Large	2,500-50,000	112,500	1,338	118,084	1.66
Huge	>50,000	225,000	2,665	461,168	0.76

Payback Period





The Australian Wine
Research Institute




The future?



The Australian Wine
Research Institute



Electrode



Ferment Simulator 2017



The Australian Wine
Research Institute



The Australian Wine
Research Institute



Dashboard

Tank Groups

History

Fermenter Setup

Ferment Profiles

Simulator Setup

Admin Settings

Change Site

Contact

Logout

Tank Group:

Favourites

Search:

Hide empty fermenters Sh

RF401



Diaego Shiraz 2015
Shiraz



30%

6.5 Be
17 °C

Warning rapid fermentation

RF403



Diaego Shiraz 2015
Shiraz



30%

6.5 Be
17 °C

Warning sluggish fermentation

Acknowledgements



The Australian Wine
Research Institute

Wine
Australia
for
Australian
Wine

